




COOKTOP PARTS

For Models: RF263LXTQ3, RF263LXTB3, RF263LXTT3, RF263LXTS3
(White) (Black) (Biscuit) (Stainless)

30" ELECTRIC FREESTANDING
SELF CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1	W10196159	Literature Instructions Installations Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	W10200356	Owners Manual
	W10115599	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2	W10196406	Bowl, Drip 6" Chrome (2)
	W10196405	8" Chrome (2)
3	3186231	White Cooktop
	8272527	Biscuit
	3186233	Black
4	3195060	Hinge, Cooktop (2)

Illus. No.	Part No.	DESCRIPTION
5	3196178	Screw (2)
6	308605	Relief, Strain
7	3195812	Rod, Support (2)
8	3196154	Screw
9		Element, Surface
	9761347	6" (2)
	9761345	8" (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RF263LXTQ3, RF263LXTB3, RF263LXTT3, RF263LXTS3
(White) (Black) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10009040	White Left Hand
	W10009050	White Right Hand
	W10009060	Biscuit Left Hand
	W10009070	Biscuit Right Hand
	W10009080	Black Left Hand
	W10009090	Black Right Hand
2	9757609	Nameplate
3		Panel, Control
	W10170677	White
	W10170663	Biscuit
	W10170678	Black
	W10117592	S.Steel


Illus. No.	Part No.	DESCRIPTION
4	3148954	Switch, Infinite LF/RR
	3148952	LR/RF
5	8523265	Light, Indicator Surface Unit (2)
6	3196068	Lens, Light (3)
7		Knob, Infinite (4)
	9761962	White
	9761963	Biscuit
	9761964	Black
8	8053912	Shield, Heat
9		Screw
	3196166	White
	8281194	Biscuit
	3196168	Black

Illus. No.	Part No.	DESCRIPTION
10	8272473	Cover, Upper
11	8273564	Clip
12		Control, Range
	W10108090	White
	W10108110	Biscuit
	W10108100	Black
	W10108100	S.Steel
13	3196178	Screw
14	9762078	Brkt-Mntg, EOC
15	W10182322	Brkt-Mntg, Console
16	3400882	Screw
17	3196200	Clip, Spring (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF263LXTQ3, RF263LXTB3, RF263LXTT3, RF263LXTS3
(White) (Black) (Biscuit) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF263LXTQ3, RF263LXTB3, RF263LXTT3, RF263LXTS3
(White) (Black) (Biscuit) (Stainless)


Illus. No.	Part No.	DESCRIPTION
1	9760407	Brkt – Mounting
2	3186144	Box, Burner
3		Panel, Side (2)
		Incl Side Foil #45
	8053830	White
	8272519	Biscuit
	8053832	Black
4	W10067840	Screw (6)
5	8522416	Seal, Oven Door
6	9757340	Element, Broil
7	9758541	Element, Bake
8	3195809	Bumper (2)
9	9757239	Rod – Dr Switch
10	W10114344	Glide, Drawer Frnt
11	3196037	Foot, Front (2)
12	W10196451	Rod, Insl Retainer
13	8054068	Tray, Insulation
14	W10137382	Clip, Panel (6)
15	9760314	Rail, Base (2)
16	W10058460	Foot, Rear (2)
17	3196548	Thermal, Fuse
18	3196172	Screw
19	3186116	Support, Oven (2)
20	3186034	Bracket, Service
21	9761958	Block, Terminal
22	8274034	Back, Main
23	9757262	Switch, Door
24	3196701	Light Socket Assy
25	311255	Bulb, Oven Light
26	9758701	Spacer – Door
27	W10181986	Sensor, Oven
28	3196169	Screw
29	3196179	Screw
30	3196178	Screw
31	3400016	Screw
32	9758283	Cover, Box
33	9761517	Clip, Door Mntg (2)
34	W10031780	Screw
35	3196567	Screw
36	3196168	Screw
37	3196174	Screw
38	9758238	Retainer, Insl(2)
39	3196560	Screw (2)
40	9755804	Tube, Vent
41	9761013	Latch, Door
42	W10078380	Rod, Latch
43	W10107820	Latch Asy, Rear
44	112432	Nut
45	W10182346	Insulation, Side

INSULATION

8272616 Insulation, Wrap
8272612 Insulation, Back

DRAWER & BROILER PARTS

For Models: RF263LXTQ3, RF263LXTB3, RF263LXTT3, RF263LXTS3
(White) (Black) (Biscuit) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	W10138079	Rack, Oven (2)
2	9761031	Drawer, Storage
3	W10174396	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196813	Black
5		Panel, Drawer Frnt
	8053339	White
	8272501	Biscuit
	8053341	Black
6	8053334	Glide, Drawer (2)
7	3196168	Screw
8	W10031790	Screw(Stls. Model)
9	9755798	Panel(Stls. Model)
10	9757219	Handle(Stls. Modl)
11	9781235	Clip(Stls. Model)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: RF263LXTQ3, RF263LXTB3, RF263LXTT3, RF263LXTS3
(White) (Black) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10144869	Trim, Top White
	W10181675	Biscuit
	W10144870	Black
2	3196164	Screw
3	W10118384	Handle, Door White
	W10118386	Biscuit
	W10118385	Black
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Window, Inner
7	9761357	Retainer, Insul.

Illus. No.	Part No.	DESCRIPTION
8	9761493	Hinge, Door (2) WH,BT,BL Models
	9761496	S.Steel Model
9	W10118454	Glass, Outer White
	W10118456	Biscuit
	W10118455	Black
	W10144884	SS Model
10	8523172	Trim, Side White Left Hand
	8523166	White Right Hand
	8523173	Biscuit Left Hand
	8523167	Biscuit Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand

Illus. No.	Part No.	DESCRIPTION
11	3196160	Screw
12	8523175	Trim, Lower White
	8523178	Biscuit
	8523177	Black
	8523180	Black (Used on S.Steel Model)
13	8272618	Insulation
14	3186289	Frame, Window
15	W10031780	Screw
16	8522414	Seal, Window
17	W10113759	Strap, Door
18	3196794	Bracket, Window
19	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: RF263LXTQ3, RF263LXTB3, RF263LXTT3, RF263LXTS3
(White) (Black) (Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black
	12 Ga. 150° c
242821	Wire, Blue
	14 Ga. 150°c
242822	Wire, Brown
	14 Ga. 150°c
242830	Wire, Brown
	14 Ga. 200°c
242823	Wire, Green
	14 Ga. 150°c
242824	Wire, Orange
	14 Ga. 150°c
242825	Wire, Red
	14 Ga. 150°c
242831	Wire, Red
	14 Ga. 200°c
242827	Wire, Yellow
	14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass
4396923	Pan, Broiler

ANTI-TIP KIT

W10017440	Anti-Tip Kit
-----------	--------------

WIRING HARNESS PARTS

W10084660	Harness, Wire (Sensor/Dr Switch)
9761476	Harness, Surface Unit
311227	Wire, Ground
3196154	Screw
W10114335	Harness, Wire (Main)
313660	Clip, Wire Ground
3196173	Screw
308605	Relief, Strain
3196174	Screw (Grnd Wire / Back)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST